

# Ammiro Dryback Installation Instructions



Before installation:

- Make sure the subfloor is clean, dry and free of any dust or dirt.
- Repair any imperfections, such as cracks, gaps and undulations.
- Keep the room temperature constant for 24 hours before fitting.
- Check relative humidity of the subfloor is below 70%.
- During this period, leave your InstaLay underlay in the room to acclimatise and relax. Make sure all packs are lying flat on the floor.
- Switch on underfloor heating 7-14 days before laying Ammiro Dryback and then switch off at least 3 hours before laying the planks/tiles.
- Make sure all planks/tiles are present, correct and in perfect condition before you get started. Check back of planks/tiles are dust-free. If not, wipe off with a damp cloth and allow to dry.

Installation:

- Use a trowel to spread Bostik Vinyl Adhesive over the subfloor. Hold the trowel at an angle of 60° to spread adhesive evenly.
- Wait until adhesive has started to dry and feels tacky. (This will take about 30 minutes at normal room temperature)
- You will have about 2 hours to lay the floor before the adhesive sets hard.
- Lay the planks/tiles directly onto the adhesive, with the edges of each plank/tile butting up neatly next to each other.
- To cut a piece of Ammiro Dryback, use a sharp knife to score the top surface. You will then be able to easily snap along this line. (Make sure you're wearing protective gloves!)
- Remove any excess adhesive from finished floor surface immediately.
- Roll the floor with a 68kg (approx.) floor roller after laying and a smaller roller for more awkward areas such as under radiators and around doorways.
- Remember to clean any adhesive off your tools before it dries.

After installation:

- DO NOT switch underfloor heating on for at least 48 hours.
- DO NOT put any furniture or heavy items on the floor for at least 24 hours.
- Avoid dragging any heavy or sharp items across the floor as this can scratch the surface. Use felt pads under furniture feet, chair legs, table legs etc.
- DO NOT fix any items permanently onto, or through, the floor.
- Clean and protect your Ammiro Click floor using a vacuum cleaner or soft mop regularly to remove any dirt and grit which could damage the surface.
- DO NOT use a steam cleaner.